1. Screws into recessed light socket

Easy as changing a light bulb. First adjust cord length. Simply screw the socket adapter into your existing recessed light.

2. Adjusts cord length up to 48”

Wrap the cord around the spindle arm to adjust the cord length to your desired height. Change it any time. No tools required.

3. Hides your existing recessed light

The decorative ceiling canopy slides up tight against the ceiling to hide your existing recessed light.

4. Holds canopy in place

No tools required. Simply turn the compression nut clockwise to tighten and counter-clockwise to loosen.

5. Looks great

Actual styles and finish of shades and lamp cup vary based on the item chosen.